

Important Safeguards and Warnings

Do not place any heavy objects on the NVR.

Do not spill liquid onto the NVR.

Please brush the printed circuit boards, connectors, fans, machine box and so on regularly.

Before cleaning the equipment, please switch off the power supply and unplug it.

Do not disassemble or repair the NVR by yourself. Do not replace the electronic components by yourself.

Contents

1. Production Introduction	3
1.1 Product Overview.....	3
1.2 Main Functions	3
2. Open-package check, products understanding and cable connections	4
2.1 Open-package check	4
2.2 Understanding of the front panel	4
2.3 Understanding of the rear panel	6
2.4 Installation connections sketch map	6
3. Basic Operation	7
3.1 Login	7
3.2 Preview	7
3.3 Desktop Shortcut Menu	7
3.3.1 Guide	8
3.3.2 PlayBack	9
3.3.3 Record Mode	10
3.3.4 PTZ Control	10
3.3.5 Highspeed PTZ	11
3.3.6 Output Adjust	11
3.3.7 Digital Channel	12
3.3.8 Version Info	12
3.3.8.1 Version	12
3.3.8.2 HDD Info	12
3.3.8.3 BPS	13
3.3.8.4 LOG	13
3.3.8.5 Online User	14
3.3.9 Logout	14
4. Main Menu.....	15
4.1 General	15
4.2 Record.....	16
4.3 Network	18
4.3.1 Net Service	18
4.4 Alarm	20
4.4.1 Motion Detect	21
4.4.2 Video Blind	22

4.4.3 Video Loss	22
4.4.4 Alarm input	23
4.4.5 Alarm output	23
4.4.6 Abnormality	23
4.5 Switch	24
4.5.1 Channel Type	24
4.5.2 Remote Device	25
4.5.3 Channel Status	27
4.6 System Management	27
4.6.1 HDD Manage	28
4.6.2 PTZ configuration	29
4.6.3 GUI Display.....	29
4.6.4 Backup	30
4.6.5 Account	31
4.6.7 Restore	33
4.6.8 Auto Maintain	33
5. Network access settings and cloud technology introduced	34
5.1 LAN access settings	34
5.2 Cloud technology functions and using introduction	36
5.3 Client CMS software operation	36
5.4 Mobile Phone monitoring	37
Appendix 1. Remote controller operation	37

1. Production Introduction

1.1 Product overview

The NVR series which is an outstanding digital surveillance product has been designed especially for security and defense sector.

It introduces embedded LINUX operating system which is more stable and robust and also brings H.264/H.265 video compressed format and G.711A audio compressed format which promises high quality images, low error coding ratio and single frame playing. To achieve strong network communication and telecommunication ability it introduces the TCP/IP network technology that runs seamlessly.

The NVR can be used individually or online connected as a part of a safety surveillance network. With the professional network video surveillance software it achieves the strong network communication and telecommunication ability

1.2 Main functions

Real-time surveillance

- VGA interface and HDMI interface surveillance functions through monitor or display.

Storage

- NVR constantly writes massive data to storage so a new, healthy, and high-performance disk is recommended.
- Special storage format which ensures the data safety.

Compression

- Real-time compression by individual hard disk which ensures the stable synchronization of audio and video signals.

Backup

- Through SATA interface and USB interface such as USB equipment, removable hard disk and so on.
- Download files through internet in the hard drive or USB.

Playback

- Individual real-time video recording as well as searching, playback, network surveillance, recording check, downloading and so on.
- Multi-channel playback mode.
- Zoom at arbitrary region.

Internet operation

- Real time remote viewing, accessing Settings remotely, video downloading and backup options.
- Remotely access PTZ.
- Remotely access the recording and real-time playback.

Alarm linkage

- Only one channel relays alarm output which is convenient for the alarm linkage and light control at the spot. (Optional).
- protecting circuits at the alarm input and output interface which protects the main machine from damage.

Communication interface

- Rs-485 interface which fulfills the alarm input and PTZ control.
- Standard Ethernet network interface which fulfills the telecommuting function.
- IPC signal input function.
- With USB interface, 3G and WIFI network connection
- Bluetooth Mouse.
- Fast copy and paste operating for the same setting.
- Support cloud access technology which makes network monitoring more easily

2. Open-package check, Products understanding and cable connection

2.1 Open-package check

When you receive the NVR, please inspect it thoroughly
First, please check whether there is any visible damage to the package appearance.
Then, please open the machine crust and check the data wire in the front panel, power adapter, the connection between the fan power and the main board.

Note:

Labels which are affixed on the products are very important. Please keep them protected
You will need to provide serial number of the product which is mentioned on the NVR in case of contacting our customer service executives.

2.2 Understanding of the front panel

Front panel button operation function table

Note: This manual is a generic manual. Please ask the retailer for a detailed description about the product



NVR Front Panel


No.	Button name	Mark	Function
1.	Direction button		Remove the cursor
			Add or decrease number during the user edit state
			Change the setting in the menu
			Surveillance pictures, into the single channel or multi-channel image surveillance.
	Main menu / function	Enter	Remove the cursor when the main menu or sub menu is popped up
			Remove the cursor during the playback mode
2.	Cancel button	ESC	Back to the previous menu or cancel operation in the operation menu
			Back to the real-time surveillance during the playback state
3.	Play preview file button		Play previous video during the playback state
4.	Play next file button		Play next video during the playback state
5.	Show play		Play in the multi-low or regular speed video during the playback state
6.	Fast play		Play in the multi-fast or regular speed video during the playback state
7.	Playback/pause button		Playback the video or pause during the playback state
8.	play/pause button		Play the video or pause during the playback state
9.	Network connection indicator light	 LINK	Network connects normally if lighted
10.	Alarm indicator light		Trigger alarm if lighted
11.	Power indicator light		Trigger alarm if lighted
12.	Recording indicator light		Trigger alarm if lighted

Table 2.1 Front panel button operation function table

5

2.3 Understanding of the rear panel


Note: Below are rear panels of some of our representative models. Please take the real object as final, these are just for reference



(1) Network interface (2) Audio input/ audio output (3) VGA output (4) HDMI interface
 (5) USB3.0 interface (6) USB2.0 interface (7) RS-485 interface video (8) Power jack

Note: Some models have front panel USB interface, this interface with the top of the rear panel USB port are mutually exclusive, only one interface is effective at the same time. USB at the bottom of rear panel is independent and effective.

2.4 Installation connections sketch map



The diagram shows the following connections:

- IP-Camera connected to Switches
- Internet connected to Switches
- Audio Input connected to the device
- VGA Output connected to a monitor
- PTZ Interface connected to a camera
- USB 3.0 Fast Backup connected to a drive
- Audio output connected to a speaker
- HD-Port Output connected to a monitor
- Mouse connected to the device
- Power Interface connected to a power source

6

3. Basic operation

3.1 Login

When the NVR boots up, the user must login and the system provides the corresponding functions with the user right. There are 3 user settings: Admin, Guest and Default. The default password for Admin user settings is 'null' and the user can create guest user account as per requirement. Admin user is master user having all the rights. Guest and default users can be allotted the rights as per requirements.



Picture 3.1 SYSTEM LOGIN

Password protection: The account will be blocked if you enter wrong password continuously five times and after half an hour the same will be unblocked automatically. If you enter wrong password for consecutively seven times then the alarm will start. You can modify the username and password after first login.

3.2 Preview

You can right click mouse to choose the switch between the windows. The system date, time and channel name are shown in each viewing window. The surveillance video and the alarm status are also shown in each window.

1.		Recording status	3.		Video loss
2.		Motion detect	4.		Camera lock

3.3 Desktop shortcut menu

On the right click of mouse, you will get the desktop shortcut menu as explained in picture 3.2. The menu includes: **Main Menu, Guide, Playback, Record Mode, PTZ control, High-speed PTZ, Color Setting, Output Adjust, Info, Logout, View 1, View 4, View 8, View 9, View 16 and Hide.**



Picture 3.2 Desktop shortcut menu


3.3.1 Guide

This function can guide user to open "Cloud service" → "QR code" → "Network config." → "Remote device" and so on.



Picture 3.3 QR code

In "Network config.", setting IP Address, Network Testing, Subnet Mask, Gateway, Primary DNS, Secondary DNS, TCP Port, MTU Port, HTTP Port, HS Download, Transfer Policy and so on. As picture 3.4:



In Network testing, test whether NVR is connected with router or other network device properly.

Step: Input IP address directly and click PING. Picture 3.5.




Picture 3.5 Network Testing

3.3.2 Playback

Play the video files in the hard disk.

Select " " desktop shortcut menu "→" playback"→ "search"→"play" option will appear.

Note: The hard disk that saves the video files must be set as read-write or read-only state.



Picture 3.6 Playback

1. HDD switch
2. recording search calendar
3. recording search
4. playback channel selection
5. playback page switch
6. playback time selection
7. Playback time period, click progress bar then can playback
8. playback file type
9. playback control keys

Synchronization: Mode: to realize multi-channel playback synchronously.

[Playback control] Refer to the following sheet for more information.

Button	Function	Button	Function
▶/	Play/Pause	◀	Backward
■	Stop/Close	◀◀	Fast back play

Form 3.2 Playback control key list

	Full screen		Fast play
	Previous frame		Next frame
	Previous file		Next file
	Circulation		Cut (some models without)


Form 3.2 Playback control key list

Special Functions:

Local zoom: When the system is in single-window full-screen playback mode, you can drag your mouse in the screen to select a section and then left click mouse to select local zoom. Press right click of the mouse to exit.

3.3.3 Record Mode (take 16CH NVR for example)

Please check current channel status: "●" means it is in recording status.



Picture 3.7 record mode

Schedule: It records according to the set parameters in "main menu" "record" "record plan".
Manual: You can either select all channels or any particular channels for recording as per your requirements.

Stop: To stop recording, you can select all channels or specific channels.

3.3.4 PTZ Control

The Functions include PTZ direction control, step, zoom, focus, IRIS, setup operation, patrol between spots, trail patrol, boundary scan, assistant switch, light switch, level rotation and so on.

The operational interface is as follows:



Picture 3.6 Playback

- Speed:** Set the PTZ rotation range. Default range: 1 ~ 8.
- Zoom:** Click - / + button to adjust the zoom.
- Focus:** Click - / + button to adjust the focus of the camera
- Iris:** Click - / + button to adjust the iris of the camera.
- Direction control:** Control the PTZ rotation. Supports 8 directions controls .
- PTZ Trace:** Full-screen shows channel image. Press left click of the mouse to control PTZ rotation orientation.
- Set:** Enter the function operation menu.
- Page Switch:** Switch between different windows

3.3.5 High Speed PTZ

After choosing, it displays the chosen channel in full screen mode. Click left button of mouse to control the PTZ to fast move and orientation. can adjust camera's magnification function by moving mouse roller

3.3.6 Output adjust

Adjust output area parameters



Picture 3.9 Output

3.3.7 Digital Channel

System Information menu items include: **one key add, Channel Management, Channel Status.**

3.3.8 Version Info

System Information menu include: **Version, HDD Info, BPS, LOG, Online Users.**

3.3.8.1 Version

Displays the basic information such as hardware information, software version, MAC, issue date and Serial No and so on.
 Note 1: The Serial No is needed when using cloud technology, please enter the Serial No correctly for remote access otherwise you can't login.
 Note 2: MAC is the MAC address of the device, also is the device mark when login by device with ARSP service; please enter the MAC address correctly while using ARSP service to access device remotely otherwise you can't login.


(Some model without ARSP function) .



Picture 3.10 Version information

3.3.8.2 HDD Info


Display the hard disk state: hard disk type, overall capability, residual capability, the recording time and so on.



Picture 3.11 hard disk information

3.3.8.3 BPS

Displays the code stream **Kb/S** and hard disk capability **MB/H** in real time.




Picture 3.12 Code stream statistics

3.3.8.4 LOG

Look up system log according to the set mode.


Log information includes: system operation, configuration operation, data management, alarm affair, recording operation, user management, and file management and so on. Set the time section to look up and click the look up button. The log information will display as a list. You can press delete button to clear all the log information.



Picture 3.13 log information

3.3.8.5 Online User

Look up the network user information in the local NVR. You can lock the user by selecting the user and then pressing disconnect button. The user will be locked until next boot-strap.



Picture 3.14 online user.

3.3.9 Logout

Logout, shutdown the system or reboot up.



Logout: Logout from the device.

Shutdown: The device will shut down

Reboot: The device will restart

4. Main menu

After login in, on the right click of mouse, the shortcut menu will appear at the bottom of the screen. To enter the main menu interface, left click the mouse.



Picture 4.1 Main menu

4.1 General

General information configuration.(as shown in Picture 4.1 Main menu)

Language: choose related operating language

Video standard: Set Device's video system (PAL or NTSC are optional)

Resolution: Set output resolution

System time: Set Device's current date &time and date & time format

HDD full:Stop: the hard drive is full, stop recording.


Select overwrite: when the hard drive is full, overwrite the earliest recorded files.

NVR No: using under the situation one remote controller controls many NVRs. Only click "ADD" on remote control and enter local number, the related NVR can respond.

Re: when "Local No "is "0"

Transparency: Adjust the transparency or operating menu

Tour: set screen tour display shows tour was opened. Single screen, four screens, eight screens, nine screens, sixteen screens etc. separate mode and mixed mode tour are optional. (As 16CH for example as below)



Picture 4.2Tour setting

4.2 Record

Set recording parameter (main stream) and network parameter (extra stream) of video and audio signal.

Set the Device's recording plan.

Note: There is at least one read-write hard disk.



Picture 4.3 Record config

Channel: Choose the corresponding channel number to set the channel. Select all the options to set all the channels

Set: Recording parameter (main stream) and network parameters (extra stream) illustrate

Video/Audio: Set whether to record video and audio simultaneously.

Resolution: Set recording resolution. The Higher resolution, the better recording quality and occupies more HDD capacity. Conversely, the lower resolution, the worse recording quality occupies less HDD capacity.

Frame Rate (FPS): set recording FPS; if the FPS is higher then it will provide better recording quality and occupy more HDD space. If the FPS is low then it will occupy less HDD space hence, low video quality.

Bit Rate Type: Set whether recording stream changes automatically according to image changes. There are six grades to choose from as per your requirements

Quality: Adjust the video quality.

Bit Rate (Kb/S): set recording stream statics under fixed stream state; if the Higher Stream statics is selected then recording quality will be better and occupies more HDD capacity. Conversely, the lower Stream statics will result in the low recording stream statics quality and occupies less HDD capacity.


Note: when NVR cannot identify the IP camera, the above recording parameter can be set manually. The device will record according to selected setting.



Picture 4.4 Recording Plan

- Channel:** Choose the corresponding channel number to set the channel. Choose all the options to set all channels.
- Redundancy:** Choose the redundancy function option to implement the double backup function. Double backup is writing the video files in two hard disks. When you do the double backup, make sure that there are two hard disks installed. One is read-write disk and the other is redundant disk.
- Length:** Set the time length of each video file. 60minutes is default duration (A maximum of 120 minutes can be selected).
- Pre Record:** Record 1-30 seconds before the action. (Time length is decided by the code stream)
- Mode:** Set video state: configuration, all or stop.
- Schedule:** You can select recording type i.e. Regular, Alarm (Detect) and time based recording.
- Manual:** after choosing manual button, the related channel will carry common recording irrespective of the current state of the channel.
- Stop:** Click the stop button to stop recording of the channel.
- Week:** You can set any particular day or even full week for recording. It will record according to selected days.
- Period:** Set the time section of common recording, the recording will start only in the set range.
- Recording type:** Set recording type: regular, detection or alarm.
- Regular:** Perform the regular recording in the set time section.
- Detect:** The alarm will be triggered and recording will be turned on in case camera signals video loss or covered with mask.
- Alarm** Trigger the external alarm signal in the set time section. When above alarm is set as opening recording, the "detection recording" state is on.

4.3 Network



Picture 4.5 network setup

- Net Link Mod:** Select automatically or enter IP address manually.
- IP address:** Set the IP address.
- Subnet Mask:** Set the subnet mask code.
- Gateway:** Set the default gateway.
- Primary DNS:** Set Preferred DNS
- Secondary DNS:** Set spare DNS
- Media port:** Set port for recording network transmission
- HTTP port:** Set HTTP Port
- Net Service:** set all network services. Pls refer 4.3.1 network service to have detailed setting description.

4.3.1.Net Service

Advanced network functions on the configuration, double-click the Net Service button to enter the Picture 4.6 interface, first select the Network Services entry and click the Settings button, or double-click the service parameter configuration items.



Picture 4.6 network service

[EMAIL setup]

If the alarm is turned on or the alarm linkage photos are taken, the same will be sent to the given email address



Picture 4.9 EMAIL

SMTP server: for example, SMTP server address of 126 email is: smtp.126.com.
Port: Enter email server port number.
Need SSL: Decide whether using Secure Socket Layer protocol to login.
User Name: Enter the email server user name.
Password: Enter the password corresponding to the user.
Sender: Set the email sender address.
Receiver; The device will send the email to appointed receivers when the alarm is turned on. You can set three receivers at max, and separate each receiver with ";" (Semicolon + Space), receiver and sender can use same email.
Title: Please enter the subject of the message.

[DDNS]



Picture 4.11DDNS

- (1) Register yourself at www.wallcam.in and choose your domain name.
- (2) Go to main menu>>>System settings>>>Network>>>Net service and select DDNS. Choose WallCam from dropdown. Mark on Enable.
- (3) Put Domain name, user name and password which gets generated while registering.
- (4) Go to your browser and enter domain name .
- (5) Enter your user id and password to access live feed of your cameras.

Note : The DNS setup must be configured correctly in the network setup.

[Mobile monitor]

Via mobile devices, realize the equipment monitoring and other related operations of the device



Picture 4.15 Mobile monitor

Enable: Select, enable the Mobile phone function.
Port: Port: Port for mobile phone view, you need to do mapping of the port on Router.

4.4 Alarm

Alarm functions include: Motion Detect, Video Blind, Video Loss, Alarm Input, Alarm Output and Abnormality.



Picture 4.20 Alarm

4.4.1 Motion Detect

When system detects the motion signal that reaches the set sensitivity, the motion detect function and the linkage function will be turned on.
 Note: Click on the advanced button to go back to the previous page to view display surveillance screen and recording setup.



Picture 4.21 motion detect

Channel: Choose the set motion detect channel.
Enable: means that the motion detect function is on.
Period: Trigger the motion detect signal in the set time section. Each day is divided into four time sections. means the set is valid.



Picture 4.22 Make/cancel defence time quantum

Interval: Only one alarm signal is turned on even there are several motion detection signals in the set interval.
Alarm output: When sensor senses the motion, the alarm will be triggered to the NVR.
Delay: Delay a few moments and stop when the alarm state is turned off. The range is 10-300 seconds.
Record channel: Choose the recording channel (Supports multiple options). Trigger the video signal when the alarm is turned on.
 Note: Set in the "main menu" "record" "record plan" and perform the linkage recording. And set "desktop shortcut menu" "record mode" to be configured, motion detect linkage recording can work
Tour: choose the recording channel (Supports multiple options), which will preview the single screen in case of alarm alert.

4.4.2 Video Blind

When the video image is influenced by outer environment or lighting and reaches the set sensitive parameter, the video blind function and the linkage function is turned on.

Note: You would need to open the IPC video blind function first and make sure that the IPC is well connected with NVR before opening the video blind function.



Picture 4.24 Video Blind

Set method: refer to Chapter 4.4.1. Motion Detect

4.4.3 Video Loss


When the equipment cannot obtain the channel video signal, the video loss alarm and the linkage function is turned on.



Picture 4.25 video loss

Set method: refer to Chapter 4.4.1. Motion Detect
4.4.4 Alarm input

When the equipment obtains the external alarm signal, the alarm function is turned on.



Picture 4.26 alarm input

Set method: refer to Chapter 4.4.1. Motion Detect
4.4.5 Alarm output

Control alarm output state of all channels




Picture 4.27 alarm output

Configuration: Alarm is on according to the configuration.
Manual: The output of the alarm will be manual after selecting manual alarm output.
Stop: Click the stop button and the respective channel stops ringing the alarm irrespective of the channel State.

4.4.6 Abnormality

It will buzz and appear screen prompts once there is no disk, HDD wrongly connected, no disk space, network cut, IP conflict etc. The device gives signal for customers to know NVR abnormality.



Picture 4.28 Abnormality

Event Type: Choose abnormality type, support five matters
Enable: Enable these three settings
Less than: this item can be set only when matter type shows no disk space, set percentage (1-99).
 When HDD space reach this setting limitation, NVR will have cue as following two ways: Show Message Show message: pop up message frame on NVR screen
 Buzzer: NVR will signal when alarm occurs

4.5 Switch (Some model without this function)

Customers can switch channel type according to their requirements




Picture 4.29 Switch

Note 1: Different models have different channel type
 2: If not required please don't switch channel type

4.5.1 [Channel Type]

Switch channel type (the following NVR mode for example)
 1.Choose "Main Menu"➡"Switch"➡"Channel type"

2. In channel type list, there are many channel type combinations available (as picture 4.30) In digital channels, the numbers under resolutions means the maximum IP camera or other network device channels which can be connected under that resolution. Customers can choose any of the combination according to their requirement. Click "OK" to finish channel type shift. The settings will be applied after restarting the device.



Picture 4.30 Channel type

4.5.2 [Remote Device]

Used to bind signals of the channels where video input type is digital network HD signal as illustrated in picture 4.31.



Picture 4.31 Remote Device

Network configuration list: click on search to see the list of networks which are added in the device, type, IP address, remote channel information of the particular channel, etc.
Protocol: Use ONVIF&NETIP protocol for searching IP device on LAN.

Search: Search IP Device on LAN.

Add: add new IP device for this NVR channel, there are 3 ways for adding IP address:
 a. Click "+" on any channel to search the IP device and add it
 b. Click "Add" in "Online Equipment"
 c. Click "+" for related device to add IP device in "Online Equipment"

One key add: Automatic add device by LAN IP, the IP address priority added by the last digit Modify IP: Change the IP device IP address when it had been searched. as picture 4.32
 Click " " to enter.



Picture 4.32 Modify IP

Added device: displays added device in the device.
Manual Add: manual enter device's IP, user name, password, protocol and IP port.
Edit: Click " " to enter Remote access configuration, can change IPC parameters. (as picture 4.33)



Picture 4.33 Remote access configuration

Device Information: display remote IP device's system version, release date, series number.


System Time : Modify remote IP device's time.

Remote restart can restart remote IP device via local operation

Default: Restore remote IP device's parameters.

Video encode: can change IP device's stream, compression, frame rate, quality and so on as illustrated in picture 4.34.

Image color: can change remote IP device's color



Picture 4.34 Video encode

Delete [x] Click "Delete" or click " " to make IPC unbinding for the selected channel.

4.5.3 [Channel status]

Shows the maximum resolution of all digital channels, connected signal resolution and connection status.

Channel	Max. resolution	This Resolution	Connection St.
D01	1080P	1080P	Connected
D02	1080P	960P	Connected
D03	1080P	720P	Connected
D04	1080P	Unknown	Not configured
D05	1080P	Unknown	Not configured
D06	1080P	Unknown	Not configured
D07	1080P	Unknown	Not configured
D08	1080P	Unknown	Not configured
D09	1080P	Unknown	Not configured
D10	1080P	Unknown	Not configured
D11	1080P	Unknown	Not configured
D12	1080P	Unknown	Not configured
D13	1080P	Unknown	Not configured
D14	1080P	Unknown	Not configured
D15	1080P	Unknown	Not configured
D16	1080P	Unknown	Not configured


Picture 4.35 channel status

Note: While setting binding the digital signal of channel, the resolution of the IP device should be less than or equal to the NVR resolution otherwise the image will not be displayed.

Channel configuration: change IP device's configuration.

4.6 System management

Set the system parameters such as **HDD Manage**, **PTZ Config**, **GUI Display**, **Backup**, **Account**, **Device Info**, **Restore**, **Auto Maintain**, **Upgrade** and **Import/Export**.



Picture 4.36 System Management

4.6.1 HDD Management

Configure and manage the hard disk.

The menu displays current hard disk information: hard disk number, input port, type, status and overall capability.

The HDD operation includes: setup the write-read disk, read-only disk, redundant disk, hard disk format, resume default. Choose the hard disk and click the right function button to execute.

Read/Write: The device can read and write if this option is selected.

Read only: The device can only read this option is selected.

Redundant: Double backup of the video files in the write-read disk.

Format Disk: All the data will be lost after formatting the disk.

HDD No	Type	Status	Disk Spz	Read/Write
1	1-1	Read Write	Normal	465.76

Picture 4.37 HDD Manage

4.6.2 PTZ Configuration



Picture 4.38 PTZ Config

Channel: Choose the dome camera input channel.
Protocol: Choose the corresponding dome protocol. (PELCOD as an example)
Address: Set as the corresponding dome address. Default address is 1.
Baud rate: Choose the corresponding dome baud rate length. You can control the PTZ and camera.
 Default is 115200.
Date bit: Includes 5-8 options. Default is 8.
Stop bit: Includes 2 options. Default is 1.
Check: Include odd check, even check, sign check, blank check. Default is void.
Note: parameters of protocol, address, baud rate should be consistent with relative PTZ or dome. Or PTZ and dome can be controlled.

4.6.3 GUI Display

[output display]

setting the information in local preview: including time title, channel title.



Picture 4.39 GUI display

Time title: means the selective state. Displays the system data and time in the surveillance window.
Channel title: means the selective state will display the system channel number in the surveillance window.
Recording status: means the selective state will display the system recording status in the surveillance window.
Alarm status: means the selective state will display the system alarm status in the surveillance window.
De-flick : select to, enable this function.

4.6.4 Backup

You can back up the video files to external storage.

Note: The storage must be installed before the file backup starts. After the completion of backup, the copied files can be played back individually. Even if the back is stopped midway, the copied files can be played back individually.



Picture 4.40 Backup

Detect: Detect the storage connected with the NVR such as hard disk or universal disk.
Backup: Click "backup" button and the dialog box will appear as in picture 4.41. You can choose the backup file accordingly.
Erase: Choose the file to delete and click erasure to delete the file.
Stop: Stop the backup.



Picture 4.41 Backup

Remove: Clear the file information.

Add: Showing the file information illustrating the set file attributes.

Start/pause: Click the play button to start the backup and click the pause button to stop the backup.

Cancel: During backup you can exit the page layout to carry out other functions.

Backup format: H.264/H.265 and AVI are optional

4.6.5 Account

Manage the user purview.

Note:

1. You can add or delete names according to user definition. The factory setup include: user/admin. You can set the user names as per your requirement. The user can appoint the purview in the team.

2. The user management includes: team/ user. The team and the user name cannot be the same. One user belongs to one team only.



Picture 4.42 user management

Modify user: Modify the existing user attribute.
Modify team: Modify the existing team attribute.

Modify password: Modify the user password. You can set a password of 1-6 characters. The blank ahead or behind the char string is invalid. The middle blank in the char string is valid.

Note: The user who possess the user control purview can modify his/her own or other user's password

Add user: Add a user in the team and set the user preview. Enter the menu interface and input the user name and password. Choose the team and select "cover using the user" "Cover using" means that the account can be used by multiple users at the same time.

Once you have chosen the team, the user preview can be seen as the subclass of the team. We recommend that the common users preview is set lower than the advanced user.



Picture 4.44 add user

Add Group: Add a user Group and set the function authority as shown in picture 4.45. It includes shut down, real time surveillance, playback, recording setup, video file backup and so on.



Picture 4.45 Add Group

Delete user: Delete the current user. Choose the user that needs to be deleted .Click the delete user button. The factory default user cannot be deleted (Such as :Admin, User, Default)


Delete Group: Delete the current team as shown in Picture 4.42 Click the Delete Group button as given in picture 4.46, select the group which need to remove from the team, click the delete button.



Picture 4.46 Delete Group

4.6.7 Restore


The system resumes the default setup. You can choose the items according to the menu.



Picture 4.48 Restore

4.6.8 Auto Maintain

Users can set the device to automatically reboot the system and the can also be deleted automatically according to the set time period.



Picture 4.49 Auto Maintain

5. Network access settings and cloud technology introduction

5.1 LAN access settings

1. Network connection

1. Before the WEB operation, you must connect this device with the network.
2. Go to NVR "main menu" → "network" to set IP address, subnet mask and gateway port (the IP segment of the device should be the same with PC computer, if disconnected, please check device IP).


2. Login

Step 1: Open a web browser; enter the IP address of the login device in the address bar. As the device with IP address 192.168.1.110, HTTP port 80. For example, enter: http://192.168.1.110 in the address bar and connections and if HTTP port is not 80 or 81, then need incorporate the port as: http://192.168.1.110:81

Step 2: Login by entering the user name and password, the default user name is admin and password is 'null' as illustrated in picture 5.1.




Picture 5.1 Login interface



Picture 5.2 Stream selection

3. Choose the bit stream the to review



Picture5.3 IE Access Interface

A District

Client Video: We can watch the video of any particular channel in this function.
Auxiliary Stream: Click to auxiliary stream to monitor a particular channel.
Main Stream: Click on a particular channel to view the same on main stream.

B District

Full Screen : Full screen monitor interface.
Single screen: Set the screen for single channel monitoring state.
Four screen: Set the screen to monitor state 4 channels.
Zoom: Click on zoom button, drag your mouse in the available screen area of any size in the selected area. By clicking the left mouse button, you can zoom in this area of the screen and right click of the mouse button to exit the enlarged screen.
Full Screen play: Open all channels monitored
Close Full Screen: Close all channels monitored
Screenshot: click the current monitor channel screen to take screen shot.
Full Channel Video: Open all current video channel
Close Full Channel Video: The option will close current channel.

C District

Playback: Playing available video files.
Log: display the current alarm log and log operation of the equipment.
Device: to set up for the various parameters of the device.
Local Configuration: Internet explorer has the address of client's video and external alarm storage location.
Exit: Exit back to the login screen.

D District: PTZ Control Can control PTZ, setting between the preset point, cruise, etc.
E District: Adjust the information such as the color of the currently selected channel.
F District: Monitor display area

5.2 Cloud technology functions and usage introduction

A. Main features of cloud technology

One step to remotely access your NVR over the Internet. No need to have professional network knowledge, DDNS and port mapping. You can instantly connect your device and start viewing remotely.

B. WAN (Wide area network) remote access & Cloud technology usage

1. Open cloud access website in your browser. Go to desktop shortcut menu >>>> System information >>> version >>> cloud server address.

There are two ways to remote control the device using cloud technology:

1. Login by registration : You can create your user name and password by visiting www.dvrcenter.net. Fill up the necessary details and click on to generate your user name and password.



You can add multiple devices in your account as per your requirements. (Picture5.5)

2. Login by Device: Enter Serial No of NVR to remotely access your NVR. To get serial number of your device, go to desktop shortcut menu >>>> info >>>> version >>>> serial number.

5.3 Client CMS software operation

CMS software is powerful central control software. Distributed architecture, set multiple windows, multi-user, multi-language, voice intercom, alarm centers and other functions. The software interface is user friendly, easy to operate. Instructions are given in the CD to install the CMS software. After installing the same in your PC, double-click on the icon to open the login screen. The default password is 'null'.

5.4 Mobile Phone Monitoring

The device allows you to remotely view the streaming of your NVR on your smartphone. It supports channel switching and multichannel monitoring.

Please follow the below cited steps :


Android and iOS users can download 'Goodeye' application from playstore or appstore.

a.Go to Local Login and click on add device.

b.Enter device name(you can put any name in this field) and serial number.

c.Select the 'Higher' options and enter NVR user name and password to login.

Appendix 1. Remote controller operation



Serial number	Name	Function
1	Multi-window button	Same function as Multi-window button in the front panel
2	Numeric button	Code input/number input/channel switch
3	Esc	Same function as Esc button in the front panel
4	Direction button	Same function as direction button in the front panel
5	ADD	Input the number of NVR to control it
6	FN	Assistant function
7	Record control	Control the record
8	Record mode	Same function as "Record mode"

Notes:

- For detailed operation introduction, please download detailed manual from our website www.videoconwallcam.com
- All the designs, software and user interface are subject to change without prior written notice.
- All trademarks and registered trademarks mentioned are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website or contact your local service engineer for more information.
- The user interface may change for different smart phone apps, the above is an illustration to configure one of the smart phone.
- All the features and specifications mentioned in this manual may vary model to model.



WallCam
Network Video Recorder